

TRANSIT OFFROAD.com

Hood Light Mount Bracket Installation Guide

Thank you for purchasing from Transit Offroad!

NOTE: We recommend that a certified mechanic install the skid plate. Some drilling will be necessary.

1. Before removing the hood mounting bolts use a pencil to score the current position of the hinge brackets, so that the alignment stays the same after installation.
2. Using a 13mm socket remove the nuts securing the hood to the hinge bracket.
3. To install the brackets as shown below for the driver side and the opposite for the passenger side (refer to video on the product page of our website for mounting instructions.)



4. Align the hinge bracket with the lines you scored in step 1 and re-install and tighten the nuts.

5. Place the notched anodized aluminum spacer on the top of the bracket and slide the KC light through it as shown.



6. Place the nut into the other anodized spacer as shown.



7. Screw spacer with nut in from the bottom of the bracket. Insert a 4mm allen key into the notched hole on the side of the lower spacer and turn the light while holding the 4mm key until hand tight. Set the light into its final position then turn the 4mm allen key ¼ turn to finish tightening.



You have now completed the installation of your new hood light brackets!

For questions regarding installation call us at: **(909) 971-3774**

Foes Fabrications Inc.
930 N Amelia Ave
San Dimas, CA 91773
Info@transitoffroad.com
